



# EXPANDA BED END COVERS 2015

## **FRONT BED PRESS STUD**

### **BRACKET LOCATIONS.**

1. Screw brackets to the inside of bed surround
2. Fit lower press stud bracket 130mm from the lower inner edge of bed surround

*Press stud bracket part number C2725B*





# EXPANDA BED END COVERS 2015

## REAR BED PRESS STUD

### BRACKET LOCATIONS.

1. Screw brackets to the inside of bed surround
2. Fit lower press stud bracket 195mm from the lower inner edge of bed surround

*Press stud bracket part number C2725B*





# EXPANDA BED END COVERS 2015

## TRACK LOCATIONS and SIZES

Please note: Ensure surface is clean before applying track

1. Apply 18mm Double side 3M tape (C2449E) cut to 75mm evenly spaced along track. See diagram
2. Apply adhesive silicone to the remaining areas.
3. Secure track to be lid as per locations below
4. Leave to bond overnight for best before fitting covers

